

Fitting Castors to your Sunranger Umbrella Base



Each castor comes with 2 flat washers, 1 spring washer and a dome nut.



It works best to first fit the spigot to the umbrella base first. (see separate instructions) Then turn the baseplate on its edge and begin installing the castors in the holes. Remove the dome nut and push the bolt through the hole. The washers should be on the underside. Fit the dome nut on the top side.

The dome nut can be tightened using the spanner in the spigot-box but you will need another spanner to hold the bolt on the underside to prevent it twisting. Repeat on all 4 corners.



It's recommended that when you move the base into place that you lock all castors to stabilise the umbrella. It is also recommended that you turn the castors inwards so they don't stick out which could cause a trip-hazard. Don't forget to unlock the castors before moving.

The castors lift the baseplate higher than normal so you must collapse and secure the umbrella in breezy conditions to prevent it from toppling or moving. Check periodically to ensure castors are tightly secured to the base.

If you have any questions please don't hesitate to contact us at Shade Australia Pty Ltd – www.shadeaustralia.com.au 1800 155 233